

## F592 Contact Spray Adhesive

**Versatile contact adhesive** for bonding a **wide range of floorcoverings**.

- **High Adhesives Content**
- **Excellent Bond Strength**
- **High temperature resistance**
- **Quick Drying**
- **Easy to Use**
- **CFC free**

### Description:

F592 is a versatile spray adhesive. Its high solids/low solvent formula produces a quicker, stronger, more aggressive bonding system which outperforms all conventional aerosol adhesives. Furthermore it has an excellent high temperature resistance (90°C), making it suitable for a wide range of applications.

### Uses:

F592 Contact Spray Adhesive is suitable for the permanent bonding of carpets, carpet tiles, most vinyl coverings, PVC skirting, fabrics, cork, paper, underlay, felts and much more.

Not suitable for polyurethane backed or highly plasticised PVC floorcoverings.

### Sub-Floors:

F592 Contact Spray is suitable for bonding to Concrete bases, cement screed, smoothing & levelling underlayment, flooring grade chipboard, hardboard, plywood, stone, terrazzo, quarry tiles, ceramic, brickwork and plaster. It is also suitable for bonding to metal, glass and most plastics.

### Specification:

Adhesive Type:	SBR Resin
Colour:	Light Beige
Flashpoint:	Highly Flammable
Coverage:	Approximately 1.5m <sup>2</sup> per 500ml can on a dual surface application
Application Temperature:	+10°C - +30°C
Drying Time:	Approx. 1 hour, depending on temperature, humidity & subfloor.
Storage & Shelf Life:	12 months in original, unopened container stored between +5°C and +25°C.
Container Size:	500 ml Can



### Directions for Use:

#### IMPORTANT

Before using F592 Contact Spray Adhesive please refer to the safety guide and data sheet available at [www.floorwise.co.uk](http://www.floorwise.co.uk)

All phases of the installation should comply with the latest editions of the following standards:

- BS 8102 Code of Practice for the protection of buildings against water from the ground.
- BS 5325 Code of Practice for the installation of textile floorcoverings.
- BS 8203 Code of Practice for the installation of resilient floorcoverings.

### Preparation:

Surfaces to be bonded should be clean, dry and dust free.

Shake can well before use.

### Application:

Spray an even coat of adhesive onto both surfaces. Allow adhesive to become touch dry, so that it does not transfer to finger, which can be almost immediately.

Press floorcovering firmly into place, which will bond immediately.

Allow 24 hours for full cure to be achieved.

After use invert can and press nozzle to clear adhesive from spray tip.

### Cleaning:

Remove any over spray immediately with Floorwise solvent cleaner or minimum of white spirit.

## F592 Contact Spray Adhesive

### Safety Guidance:



<b>DANGER</b>	<b>F.592 Contact Spray Adhesive</b>	<b>UN1950</b>
  	<b>Contains: DICHLOROMETHANE</b>	
	<b>Hazard Statements</b> Extremely flammable aerosol. Pressurised container: may burst if heated Causes skin irritation Causes serious eye irritation May cause drowsiness or dizziness. Suspected of causing cancer	
	<b>Precautionary Statements</b> Keep away from heat/sparks/open flames/hot surfaces. No Smoking Do not spray on an open flame or other ignition source. Pressurised container: Do not pierce or burn, even after use. Use only outdoors or in a well-ventilated area. Wear protective gloves/protective clothing/eye protection/face protection. Protect from sunlight. Do not expose to temperatures exceeding 50°C. Repeated exposure may cause skin dryness or cracking.	
	<b>KEEP OUT OF REACH OF CHILDREN</b>	
	Dispose of contents/container in accordance with national regulations	
<b>500 ml</b>	Label in accordance with (EC) No. 1272/2008	

A full materials safety data sheet relating to this product is available at [www.floorwise.co.uk](http://www.floorwise.co.uk)

This product data sheet is provided for guidance only. For further information and advice on application, or if in any doubt as to the suitability of the product for the installation, please contact our Technical Department for advice.